

MINI BENDER

Combo

The Pedal is equipped with n.o.s. germanium transistor and it is sensitive to the ambient temperature.

- Do not expose it to direct sunlight
- Do not expose on heat sources or over the Amp
- best temperature is between 18 and 25 Degrees
- put it for first In the Effects Chain, Right after the guitar.

Controls:

Level-This controls the output of the pedal. Turn left for less and right for more volume.

Attack-This controls the amount of fuzz. Turn left for less and right for more.

Mk1.5 - PROII toggle Switch:

This Switch the Effect from the Bender Professional MkII to the Bender Mk1.5

Connection Jack:

Input: Located on the top right.

Connect this to your guitar

Output: Located on the top Left.

Connect this to your amplifier or next pedal.

9V Powered Negative Tip.

The pedal uses a special circuit that reverses vintage positive ground, so **you can** daisy-chain its power supply with the other pedals